



BENASSI — 24

RS40 E — 25

40 — 26

— 26

POS.	CODICE	DESCRIZIONE	Q.TA'	POS.	CODICE	DESCRIZIONE	Q.TA'
1	02.160.0.001.0	Scocca	1	16	02.159.0.016.0	Telaio	1
2	02.160.0.002.0	Motore	1	17	02.159.0.017.0	Sacco	1
3	02.160.0.003.0	Ventola	1	18	02.151.0.016.0	Stegola Inf.	1
4	02.160.0.004.0	Capottina	1	19	02.151.0.017.0	Stegola Sup.	1
5	02.151.0.005.0	Sportello Post.	1	20	02.151.0.019.0	Clips	2
6	02.160.0.006.0	Condensatore Cpl	1	21	02.151.0.018.0	Interruttore	1
7	02.160.0.007.0	Gr.Porta Lama	1	22	02.159.0.019.0	Lamiera Post.	1
8	02.159.0.008.0	Lama	1	23	02.015.0.069.0	Decalco Aquila	1
9	02.151.0.009.0	Molla	2	24	02.011.0.084.0	Decalco Benassi	2
10	02.159.0.010.0	Asse Ruote Ant.	1	25	02.160.0.025.0	Decalco RS40 E	1
11	02.159.0.011.0	Asse Ruote Post.	1	26	02.011.0.079.0	Decalco	1
12	02.159.0.012.0	Ruota	4				
13	02.151.0.012.0	Perno Sportello P.	1				
14	02.151.0.013.0	Volantino	4				
15	02.151.0.014.0	Molla	2				