


PARTS LIST AND INSTRUCTIONS

VERLUCHTER



AERATOR MODEL 7-2411 (Formerly SC-152)

WHEELHORSE PRODUCTS, INC. • SOUTH BEND, IND.



ASSEMBLY

Remove unit from box. There will be three (3) pieces to assemble. Remove cotter keys from axle and put on wheel supports as shown. Replace cotter keys and lock fast with thumb screws to desired position.

Slide tractor hitch through tube in box and secure by using the two cotter keys to lock fast.

OPERATION

Unit is equipped with 6" wheels for both transporting when in the down position or as gauge wheels to regulate depth desired.

The box will hold (2) standard concrete blocks which may be used if ground is hard.

Unit may be lifted with the tractor lift lever or towed on the transport wheels whichever is desired. (NOTE: Do not lift with concrete blocks on aerator.)

Spikes should be kept clean to allow unit to penetrate soil.

Oil moving parts occasionally for better performance.

PARTS LIST

Ref. No.	Part No.	Description	Quantity
1	2853	Frame & Box Assy.	1
2	2866	Hitch Bar Assy.	1
3	2160	Pivot Bar Assy.	1
4	2862	Wheel Support Assy. R.H.	1
5	2865	Wheel Support Assy. L.H.	1
6	2857	Spacer-Outer	2
7	2858	Spacer-Inner	28
8	2859	Spike	17
9	2860	Axle	1
10	2861	Compression Spring	2
11	4121	Wheel	2
12	1073	H.H.C.S. 1/2-13 x 1 3/4	1
13	1410	Nylock Nut 1/2-13	1
14	1478	Cotter Key 1/4 x 1 1/2	2
15	1017	Washer 1/2 SAE	4
16	1012	Cotter Key 3/16 x 1 1/2	4
17	2868	Thumb Screw	2
18	4411	Decal	1

